





ELEVATE YOUR CREATIVITY

Long Arm Extension Table Instructions



Long Arm Extension Table Includes:

- 16" x 15.5" Acrylic Extension Table
- 4 Adjustable Legs
- 2 Metal Brackets



Step 1: Attach legs to table


Step 2: Slide Extension Table around the base of the long arm machine, making sure the four legs are on the carriage for support.

**Note: If the legs are not on the carriage, you may need to move the machine as it is designed to be centered side to side to and be lined up with the arrow on back. Machine locks may need to be removed from one or both front slots on the carriage.*

If you had to unattach the machine from the carriage to move it into position as described above, it will be important to reattach the machine to the carriage. The metal table brackets will slide in next to black plastic carriage brackets.

Step 3: Position the metal brackets on both sides of the Extension Table's rear leg, as shown in the photo at right.

**Note: this will help keep the Extension Table secured to the carriage. If the brackets do not reach the legs on the Extension Table, you may need to adjust the position of the machine on its carriage.*



Step 4: Tighten the thumb screw under the carriage to secure bracket to the carriage.

TIP: Simply pop the Table off the back legs when not in use. This will leave back legs and metal brackets in place for quick install/uninstall.